

Mini Cordsets

Build Your Own Quick-Connex® Mini & Micro DeviceNet™ Cordsets

The chart below lists components with which to “build” the exact cordset needed.

How to use:

1. Begin at left with the first column. Write a “**C**” for cordset or a “**R**” for receptacle in the box at the top of the column.
2. From the next column, identify the style. Write the appropriate letter in the box at the top of the column.
3. Select components from all remaining columns, writing the desired letters or numbers chosen in the box at the top of each column.

Example

C	P	2	5	E	43	M	006	
----------	----------	----------	----------	----------	-----------	----------	------------	--

In the sample part number above, **CP25E43M006** is a Mini DeviceNet™ double ended cordset, 5 Pole Male straight to Female straight with Trex-Onics® DeviceNet™ Thin cable #60010, 6 meters length.

Your Selection Goes Here

Type	Style	Ends	No. of Poles	Head Config.	Cable	Unit of Measure	Length	Coupling
C = Cordset R = Receptacle	P = DeviceNet™ Mini T = DeviceNet™ Micro	1 = Single End or Receptacle 2 = Double End	5	A = Male Straight B = Male 90° C = Female Straight D = Female 90° E = Male Straight to Female Straight F = Male Straight to Female 90° G = Male 90° to Female Straight H = Male 90° to Female 90°	43 = Device Net THIN #60010 High Performance Cable 44 = Device Net THICK #60008 High Performance Cable #60008 will be replaced by Device Net THICK #60009 Cable when 60008 stock is depleted Note: Micro Cordsets are made with DeviceNet THIN cable #60010 Receptacle Part Numbers will use PT in place of a Cable Code	M = Meters F = Feet A = Inches	Enter a 3-Digit Code Example: 5 = 005 50 = 050 500 = 500	Blank = Regular S = Stainless Steel