

# Build Your Own Quick-Connex® M12 DC Micro High Temperature Silicone Cordsets

The chart below lists components with which to “build” the exact cordset needed.

**How to use:**

1. Begin at left with the first column. Write a “**C**” for cordset or a “**R**” for receptacle in the box at the top of the column.
2. From the next column, identify the style. Write the appropriate letter in the box at the top of the column.
3. Select components from all remaining columns, writing the desired letters or numbers chosen in the box at the top of each column.

**Example**

<b>C</b>	<b>K</b>	<b>2</b>	<b>4</b>	<b>E</b>	<b>94</b>	<b>M</b>	<b>004</b>	
----------	----------	----------	----------	----------	-----------	----------	------------	--

In the sample part number above, **CK24E94M004** is a M12 DC Micro High Temp double ended 4 Pole Male straight to Female straight with Thermo-Trex® 600-Plus 18/4 cable #41684, 4 meters length with stainless steel coupling nuts

**Your Selection Goes Here**

--	--	--	--	--	--	--	--	--

Type	Style	Ends	No. of Poles	Head Config.	Cable	Unit of Measure	Length	Coupling
<b>C</b> = Cordset <b>R</b> = Receptacle	<b>K</b> = DC Micro	<b>1</b> = Single End or Receptacle	<b>3-5</b>	<b>A</b> = Male Straight <b>B</b> = Male 90° <b>C</b> = Female Straight <b>D</b> = Female 90°	<b>93</b> = 18/3 #41683	<b>M</b> = Meters <b>F</b> = Feet	<i>Enter a 3-Digit Code</i>  Example: 5 = <b>005</b> 50 = <b>050</b> 500 = <b>500</b>	Blank = Stainless Steel
		<b>2</b> = Double End			<b>94</b> = 18/4 #41684	<b>A</b> = Inches		
					<b>E</b> = Male Straight to Female Straight <b>F</b> = Male Straight to Female 90° <b>G</b> = Male 90° to Female Straight <b>H</b> = Male 90° to Female 90°	<b>95</b> = 18/5 #41685  Receptacle Part Numbers will use <b>PT</b> in place of a Cable Code		