

Build Your Own High Temperature M12 DC Micro Quick-Connects™ with Thermo-Trex 600-Plus High Temperature Silicone Cable

The chart below lists components with which to “build” the exact assembly needed. Begin at left with the first column. Write a “**C**” for cord set or a “**R**” for receptacle in the box at the top of the column. From the next column, identify the style. Write the appropriate letter in the box at the top of the column. Select components from all remaining columns, writing the desired letters or numbers chosen in the box at the top of each column.

| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|--------------------------|--|---|---|---|---------------------------------|---------------------|---|
| TYPE | STYLE | ENDS | POLES | HEAD CONFIG. | CABLE | UOM | LENGTH |
| C | K | 2 | 5 | E | 95 | M | 005 |
| C = Cord Set | K = High Temp M12 DC Micro | 1 = Single End (or Receptacle) | Number of Poles: 3, 4 or 5 | A = Male Straight | 93 = 18/3 (DC) #41683 | Unit of Measure: | Enter a three digit code in the box above. |
| | | | | B = Male 90° | | | |
| | | | | C = Female Straight | 94 = 18/4 (DC) #41684 | F = Feet | EXAMPLE: 5 = “005” |
| | | | | D = Female 90° | | | |
| R = Receptacle | | 2 = Double End | | E = Male Straight to Female Straight | | | 500 = “500” |
| | | | | F = Male Straight to Female 90° | | | |
| | | | | G = Male 90° to Female Straight | | | |
| | | | | H = Male 90° to Female 90° | | | |
| | | | | R = Male Panel Mount Re- ceptacle | | | |
| | | | | T = Female Panel Mount Receptacle | | | |
| | | | | <i>For Receptacles, please use PT for Pigtails instead of the cable code, example RL14TPTF004</i> | | | |

Stainless Steel Coupling Nut is Standard