

Build Your Own Quick-Connex® DC & AC Micros SJOO Super-Trex® Cordsets

The chart below lists components with which to “build” the exact cordset needed.

How to use:

1. Begin at left with the first column. Write a “**C**” for cordset or a “**R**” for receptacle in the box at the top of the column.
2. From the next column, identify the style. Write the appropriate letter in the box at the top of the column.
3. Select components from all remaining columns, writing the desired letters or numbers chosen in the box at the top of each column.

Example

C	F	2	5	E	26	F	020	
----------	----------	----------	----------	----------	-----------	----------	------------	--

In the sample part number above, **CF25E26F020** is a M12 DC Micro double ended cordset, 5 Pole Male straight to Female straight with Super-Trex® SJOO 18/5 cable #87015, 20 feet length..

Your Selection Goes Here

--	--	--	--	--	--	--	--	--

Type	Style	Ends	No. of Poles	Head Config.	Cable	Unit of Measure	Length	Coupling
C = Cordset	F = DC Micro	1 = Single End or Receptacle 2 = Double End	3-4-5	A = Male Straight B = Male 90° C = Female Straight D = Female 90° E = Male Straight to Female Straight F = Male Straight to Female 90° G = Male 90° to Female Straight H = Male 90° to Female 90° <i>Micro Receptacles - Micros Only:</i> Q = Female Back Mount T = Female Panel Mount R = Male Panel Mount S = Male Switch Body Mount	<i>Super-Trex Micro</i> 24 = 18/3 DC #87013 25 = 18/4 DC #87014 26 = 18/5 DC #87015	M = Meters F = Feet A = Inches	<i>Enter a 3-Digit Code</i> Example: 5 = 005 50 = 050 500 = 500	Blank = Regular S = Stainless Steel P = Plastic
R = Receptacle	G = AC Micro				28 = 18/3 AC #87003 29 = 18/4 AC #87004 30 = 18/5 AC #87005 Receptacle Part Numbers will use PT in place of a Cable Code			